

Battery Removal for SGP

DOC-BMS-218A

V01

Owner TD

Page 1 of 1

At Motortronics UK, we aim to be as environmentally conscientious as we can. To this end the Battery Directive is proposing a change whereby all batteries should be readily removable and recyclable by the end-user.

These instructions show the process for doing this on our Synergy Plus units. The battery removal tool can be requested/ordered FOC via our Sales Department.

1

Place unit on flat surface.



Get
replacement
battery (CR1632
Button battery).



2

Remove
the small
expansion
slot cover
from the
cassette.
Take the
battery
removal tool and slide into the
opening towards the battery,

push lightly until you cannot

push it in further.

5

Insert battery into the opening, using the opposite end of the tool to push the



battery into its housing, when you hear a light click, stop.

3

Pull tool out slowly.

6

Remove the tool and place the panel back on.

