

## Battery Removal for AGY

At Motortronics UK, we aim to be as environmentally conscientious as we can. To this end the Battery Directive is proposing a change whereby all batteries should be readily removable and recyclable by the end-user.

These instructions show the process for doing this on our Agility units. The battery removal tool can be requested/ordered FOC via our Sales Department.

<b>1</b>	Lay unit on a flat surface.	
<b>5</b>	Get replacement battery (CR1632 Button battery).	
<b>2</b>	Remove small top cover on the cassette.	
<b>6</b>	Insert battery into the opening.	
<b>3</b>	Take the battery removal tool and slide into the opening towards the battery. Push lightly until you cannot push it in further.	
<b>7</b>	Use the opposite end of the tool to push the battery into its housing. When you hear a light click, stop.	
<b>4</b>	Pull tool out slowly.	
<b>8</b>	Remove the tool and place the panel back on.	